

Take Fashion Plates® anywhere!
Everything fits in the fashion carrying case!



Store blank paper and your finished designs in the fashion folio. The folio fits in the large pocket of the fashion carrying case.

TIP: You can refill this folio with standard 8.5in x 11in (21.6cm x 28cm) paper folded in half.

Look for these and other Fashion Plates® Expansion Sets to add more styles to your collection!

Sports Collection

Glamour Collection



Fashion Plates®

fashion folio



ideas and tips inside!



Product and colors may vary. Product duplication for illustration purposes only. Some designs shown in this guide use additional pencil colors not included in this kit.

[KahootzToys.com](https://www.KahootzToys.com) @KahootzToys

© 2016 Kahootz, LLC. FASHION PLATES is a registered trademark of Kahootz, LLC. All Rights Reserved. 772 Airport Boulevard, Suite 1 • Ann Arbor, MI 48108 www.KahootzToys.com • www.FashionPlatesToy.com


How to use Fashion Plates®

1



Place plates in the tablet

Choose plates for your fashion design. Lift the frame and place the plates in the tray of the tablet.



You can use a top piece and bottom piece, or a top, middle and bottom.

2



Add paper & rub with crayon

Place a piece of paper on top of the plates and close the frame. Hold the frame in place with one hand and use the rubbing crayon in the crayon holder to rub back and forth over the paper. This creates the outline of your fashion design.


Be sure to rub the whole design before opening the frame or moving the paper. You may need to rub over some areas more than once. Try rubbing diagonally to fill in any missed areas.

3



Flip plates to add patterns!

Flip the plates over in the tray and color with colored pencils to add patterns to your fashions.



Change and swap plates to use any patterns that you like!

Fashion ideas and tips

TIP: You can use a small plate to fill a large area with a pattern.

1. Place the plate in the tray under the paper and color with a colored pencil.
2. Move the plate to an uncolored area and color again.
3. Repeat until the area is fully colored, overlapping as needed.



TIP: You can make different patterns in the same area by switching plates and pencil colors.

1. Using one pattern plate, color only the jacket in blue.
2. Switch to a different pattern plate and color only the shirt in pink.
3. You can also remove the pattern plates to finish coloring skin and hair.



Mix and match plates and patterns to create your own unique fashion combinations!